



3: Put the tray into the small pipe and tighten screw

2: Insert the small pipe to the big pipe and tighten screw

1: Insert the big pipe into the feet